

# Capsule Conversion Instructions

---

1. Unplug unit from the wall.
2. Open both the front door and the back door.
3. Inside the back door at the bottom left there is an electronics box. Remove the nuts and take the cover off the box.
4. Find the smaller chip that matches the size of the chip you received. Remove the chip on the board and replace it with the chip labeled CAP.
5. Inside the front door, remove the yellow coin mech panel by taking out two small screws on the left and the 3 on the right hand diagonal. As you remove this panel please be cautious of the wires that are connected to the coin mech. You do not need to unplug the wires during this process.
6. Behind where the coin mech panel was, there are two black chutes. Remove one nut on the left side with a 5/16" socket and one other nut on the right hand side. You will see these chutes direct the gum from the gum wheel to the auger and the other directs the gum from the track to the exit box.
7. Attach the new capsule chutes in the same place as the previous chutes back onto the same screws the previous chutes came off of. Make sure the nuts are tight.
8. Right under where the yellow track attaches and ends at the green panel, remove the Phillips head screw. Put the green plate in to block the hole and replace the screw.
9. Place the marble into the chute leading into the auger.
10. If the wires going to the coin mech came apart at the disconnect, it does not matter which white wire attaches to red or black.
11. At this point it is wise to run a quarter through the coin mech to make sure the chutes are installed correctly.
12. If all is working well, then you can replace the coin mech panel by first meshing the coin mech gear into the slots on the gum wheel then reinserting the two screws on the left side and the three on the right side diagonal.
13. Please make sure that all is working well before you leave the machine.